# ALIGNMENT SYSTEMS **ALIGNMENT AUTOCOLLIMATORS**

## WITH STRAIGHT VIEWING



### **Description:**

An alignment autocollimator with straight viewing has the user's line of sight co-linear with the objective axis. The image of the target appears in the eyepiece focal plane laterally and vertically reverted. These alignment autocollimators are preferably used in horizontal direction, where the eyepiece is at eye level.

## WITH 90°-VIEWING



### **Description:**

An alignment autocollimator with 90°-viewing has the user's line of sight at 90° to the objective axis. The target image appears in the eyepiece focal plane upright but laterally reverted. These alignment autocollimators are preferably used downlooking or on optical tables where a straight viewing is not feasible.

381

WITH STRAIGHT VIEWING AND DIGITAL DOUBLE MICROMETER

Ord.-No.

231 902

Ord.-No.

231 901

## **Description:**

Ø 40 f7

An alignment autocollimator with digital double micrometer enables to measure the target image displacement in the eyepiece image plane. If the target distance is known, the target displacement can be calculated. Additionally, the tilting angle of the target with respect to the LOS can also be measured.



OrdNo.	Description
231 911	FAKG 300/40/14,7 MDD







Description

FAKR 300/40/14,7







Description

FAKG 300/40/14,7

COLLIMATORS

160

ΠΠΠ

